Contents

1. Introduction 1–1
   1.1. Purpose 1–3
   1.2. Key Related Bellcore/Standards Documents 1–3
   1.3. Document Organization 1–4
   1.4. Requirements Terminology 1–5
   1.5. Changes Relative to TA-TSV-001117, Issue 1 1–6

2. Overview, Assumptions, and Background 2–1
   2.1. Customer environment 2–1
   2.2. Design Principles for Exchange PVC CRS CNM Service 2–4
   2.3. Phases for Providing Exchange PVC CRS CNM Capabilities 2–5
   2.4. Alternatives for Providing Exchange PVC CRS CNM Capabilities 2–6
   2.5. LEC Network Support of CPE NM Applications 2–9
      2.5.1 PVC CRS CNM Service Access through SNMP 2–10
      2.5.2 PVC CRS CNM Service Access through ILMI 2–13
   2.6. Monitoring and Surveillance Layer Management Protocols 2–15
   2.7. LEC Network Support of PVC CRS CNM Applications 2–16
   2.8. Framework for Accessing Phase 1 Exchange PVC CRS CNM Information 2–17

3. Overview of Exchange PVC CRS CNM Service Capabilities 3–1
   3.1. Phase 1 Exchange PVC CRS CNM Service Capabilities 3–2
      3.1.1. Receive Event Notifications 3–2
      3.1.2. Retrieve General PVC CRS CNM Agent Information 3–2
      3.1.3. Retrieve UNI Configuration Information 3–2
      3.1.4. Retrieve PVC Configuration Information 3–3
      3.1.5. Retrieve UNI and PVC Performance Information 3–3
   3.2. Potential Phase 2 Exchange PVC CRS CNM Service Capabilities 3–3
      3.2.1. Request Event Notifications 3–3
      3.2.2. Modify UNI Configuration Information 3–3
      3.2.3. CRS PVC Reconfiguration 3–4
      3.2.4. Retrieve Usage Information 3–4
      3.2.5. Initiate Tests 3–4
      3.2.6. Trouble Report Administration 3–4
   3.3. Global Service Objectives 3–5
      3.3.1. Availability 3–5
         3.3.1.1 Scheduled Service Time 3–5
         3.3.1.2 Mean Time Between Service Outages 3–5
         3.3.1.3 Mean Time to Restore 3–6
      3.3.2. Capacity Objectives 3–6
   3.4. Global Security Requirements 3–6

4. Exchange PVC CRS CNM Information 4–1
   4.1 CNM Information Tables 4–3

4.2 CNM Information Requirements 4–9
4.2.1 Alarm Information 4–10
4.2.2 PVC Alarm Subscription Information 4–12
4.2.3 Exchange PVC CRS General Subscription Information 4–12
4.2.4 CNM Agent Information 4–13
4.2.5 UNI Protocol Stack Information 4–15
4.2.6 General Layer Specific Information 4–15
4.2.7 ATM Layer Configuration Information 4–20
4.2.8 Virtual Link (VCL and VPL) Specific Information 4–22
4.2.9 Traffic Characterization Information 4–24
4.2.10 PVC (VPC or VCC) Cross Connect Information 4–25
4.2.11 SONET TC Layer Performance Information 4–27
4.2.12 SONET Layer Configuration and Performance Information 4–27
4.2.13 DS3 PLCP Layer Performance Information 4–33
4.2.14 DS3 Layer Configuration and Performance Information 4–34
4.2.15 DS1 Layer Configuration and Performance Information 4–34
4.2.16 ATM Layer Performance Information 4–35
4.2.17 Virtual Link (VPL or VCL) Performance Information 4–36
4.2.18 Threshold Crossing Alert Information 4–36

5. Exchange PVC CRS CNM Service Access 5–1
5.1 CNM Service access through SNMP 5–1
5.1.1 SNMP-Based Management Overview 5–1
5.1.2 Representation and Support of CNM Information 5–3
5.1.2.1 Alarm Information 5–5
5.1.2.2 PVC Alarm Subscription Information 5–6
5.1.2.3 Exchange PVC CRS General Subscription Information 5–8
5.1.2.4 CNM Agent Information 5–9
5.1.2.5 UNI Protocol Stack Information 5–10
5.1.2.6 General Layer Specific Information 5–10
5.1.2.7 ATM Layer Configuration Information 5–12
5.1.2.8 Virtual Link (VCL and VPL) Specific Information 5–13
5.1.2.9 Traffic Characterization Information 5–13
5.1.2.10 PVC (VPC or VCC) Cross Connect Information 5–13
5.1.2.11 SONET TC Layer Performance Information 5–14
5.1.2.12 SONET Layer Configuration and Performance Information .. 5–14
5.1.2.13 DS3 PLCP Layer Performance Information 5–15
5.1.2.14 DS3 Layer Configuration and Performance Information 5–15
5.1.2.15 DS1 Layer Configuration and Performance Information 5–16
5.1.2.16 ATM Layer Performance Information 5–16
5.1.2.17 Virtual Link (VPL or VCL) Performance Information 5–16
5.1.2.18 Threshold Crossing Alert Information 5–17
5.1.3 Service Objectives 5–18
5.1.3.1 SNMP Agent Response Time 5–18

5.1.3.2 Data Currentness 5–18
5.1.4 Connectivity Options 5–19
5.1.4.1 Application Layer 5–19
5.1.4.2 Transport Layer and Network Layer 5–19
5.1.4.3 Subnetwork Layer 5–21
5.1.5 Addressing Issues 5–22
5.1.5.1 Transport Layer 5–22
5.1.5.2 Network Layer 5–23
5.1.6 Security Issues 5–24
5.1.6.1 Dial-up Line Security Issues 5–24
5.1.6.2 SNMP Security Issues 5–25
5.1.7 Management Information for an SNMP Agent 5–27
5.1.8 Subscription Parameters for Access to the SNMP Agent 5–28
5.2 ILMI 5–28
5.2.1 General Requirements 5–29
5.2.2 Service Objectives 5–30
5.2.2.1 ILMI Response Time 5–30
5.2.2.2 Data Currentness 5–30
5.2.2.3 ILMI Bandwidth 5–31
5.3 Layer Management Protocol 5–31
5.3.1 Physical Layer 5–31
5.3.2 ATM Cell Layer 5–32
5.4 File Transfer Access to Usage Information 5–32

6. Architecture to Support PVC CRS CNM Service 6–1
6.1 BSS Functions Supporting CNM 6–2
6.2 Functions Supporting PVC CRS CNM 6–5
6.2.1 Supporting Database Administration of PVC CRS CNM Subscriber Records 6–5
6.2.2 Supporting an SNMP-based Access Mechanism 6–5
6.2.3 Supporting the Capability to Retrieve PVC CRS CNM Information 6–6
6.2.3.1 The Identical Information Category 6–7
6.2.3.2 The Similar Information Category 6–7
6.2.3.3 The PVC CRS CNM-Specific Information Category 6–8
6.2.4 Supporting Event Notifications 6–8
6.2.4.1 Link Status Event Notifications 6–9
6.2.4.2 PVC Status Change Event Notification 6–11
6.2.4.3 Threshold Crossing Alert Event Notifications 6–11
6.2.5 Supporting Service Assurance 6–12
6.3 CNM integration for SMDS, Frame Relay, and Exchange PVC CRS 6–12

Appendix A: Relationship of Exchange PVC CRS CNM Information with Other ATM requirements A–1

Appendix B: Obtaining Internet Documentation B–1

Appendix C: Using the Interfaces Group from MIB II C–1
Acronyms..... Acronyms–1
References References–1