
Broadband Access Signaling Generic Requirements

Contents

Preface	Preface-1
1. Introduction	1-1
1.1 Purpose and Scope	1-1
1.2 Major Changes	1-2
1.3 Document Organization	1-2
1.4 Related Bellcore, Standards, and Industry Documents	1-4
1.4.1 Relation to National and International Standards and Industry Fora	1-4
1.4.2 Related Documents	1-4
1.5 Requirements Terminology	1-5
1.6 Requirement Labeling Conventions	1-5
1.6.1 Numbering of Requirement and Related Objects	1-6
1.6.2 Requirement, Conditional Requirement, and Objective Object Identification	1-6
2. General Description	2-1
2.1 Summary	2-1
2.2 Description	2-2
3. Physical, ATM, and Adaptation Layers	3-1
3.1 Physical Layer	3-1
3.2 ATM Layer	3-1
3.3 Meta-Signaling	3-2
3.4 Signaling ATM Adaptation Layer (SAAL)	3-2
4. Point-to-Point Call Processing	4-1
4.1 Call/Connection Establishment at the Originating Interface	4-1
4.2 Call/Connection Establishment at the Destination Interface - Point-to-Point Access Call Offering	4-2
4.3 Call/Connection Establishment at the Destination Interface - Point-to-Multipoint Access Arrangement Call Offering	4-2
4.4 Call/Connection Clearing	4-3
4.5 Restart Procedures	4-3
4.6 Handling of Error Conditions	4-3
4.7 Error Procedures with Explicit Action Indication	4-4
5. Point-to-Multipoint Call Processing	5-1
5.1 Call/Connection Establishment at the Originating Interface- Point-to-Point Access Call Offering	5-1

5.2	Call/Connection Establishment at the Destination Interface- Point-to-Point Access Call Offering	5-2
5.3	Call/Connection Clearing.....	5-2
5.4	Handling of Error Conditions.....	5-3
5.4.1	Endpoint Reference Errors	5-3
5.4.2	Mandatory Information Element Content Error.....	5-3
5.4.3	Unrecognized Information Element.....	5-4
5.4.4	SAAL Failure.....	5-4
5.5	Error Procedures with Explicit Action Indication.....	5-4
6.	Additional Procedures and Parameters	6-1
6.1	Parameters	6-1
6.1.1	Number of Allocated VPI Bits	6-1
6.1.2	Number of Allocated VCI Bits	6-1
6.1.3	Signaling Virtual Channel Bandwidth	6-2
6.1.4	Set of Valid Addresses	6-3
6.1.4.1	Simple Address Assignment.....	6-3
6.1.4.2	Extended Address Assignment	6-4
6.1.5	Default Address.....	6-5
6.1.5.1	Simple Address Assignment.....	6-5
6.1.5.2	Extended Address Assignment	6-6
6.1.6	InterLATA Carrier Presubscription	6-6
6.1.7	Calling Number Delivery	6-6
6.1.8	Calling Party Subaddress Transfer.....	6-6
6.1.9	Called Party Subaddress Transfer	6-7
6.1.10	High-layer Information Transfer.....	6-7
6.1.11	Low-layer Information Transfer	6-7
6.1.12	Low-layer Information Selection	6-8
6.1.13	ATM Adaptation Layer Parameter Information Transfer	6-8
6.1.14	Point-to-Multipoint Provision	6-8
6.1.15	IntraLATA Competition.....	6-9
6.1.16	Summary of Parameters	6-10
6.2	Timers.....	6-11
6.3	Address Registration	6-11
6.4	Determination of Resource Availability and of Busy Conditions.....	6-12
6.4.1	Bandwidth Determination	6-12
6.4.2	Busy Conditions	6-13
6.5	Call Processing Performance	6-13
6.5.1	Loss of Signaling Messages - SAAL to Q.2931	6-13
6.5.2	Corruption of Signaling Messages - SAAL to Q.2931	6-14
6.5.3	BSS Signaling Processing Delay	6-14
7.	Message Functional Definition and Content.....	7-1
7.1	Overview	7-1
7.2	Point-to-Point Messages.....	7-1

7.2.1	CALL PROCEEDING	7-2
7.2.2	CONNECT	7-2
7.2.3	CONNECT ACKNOWLEDGE.....	7-2
7.2.4	RELEASE	7-2
7.2.5	RELEASE COMPLETE	7-3
7.2.6	RESTART	7-3
7.2.7	RESTART ACKNOWLEDGE.....	7-4
7.2.8	SETUP.....	7-4
7.2.9	STATUS.....	7-7
7.2.10	STATUS ENQUIRY.....	7-7
7.3	Point-to-Multipoint Messages	7-7
7.3.1	ADD PARTY	7-8
7.3.2	ADD PARTY ACKNOWLEDGE.....	7-8
7.3.3	ADD PARTY REJECT.....	7-9
7.3.4	DROP PARTY	7-9
7.3.5	DROP PARTY ACKNOWLEDGE.....	7-9
8.	General Message Format and Information Element Coding	8-1
8.1	Overview	8-1
8.2	Protocol Discriminator	8-1
8.3	Call Reference.....	8-1
8.4	Message Type and Message Length.....	8-1
8.4.1	Message Type.....	8-1
8.4.2	Message Length	8-2
8.5	Variable Length Information Elements.....	8-2
8.5.1	Coding Rules.....	8-2
8.5.2	Extension of Codesets	8-2
8.5.3	Locking Shift Procedures.....	8-3
8.5.4	Non-Locking Shift Procedures.....	8-3
8.5.5	ATM Adaptation Layer Parameters	8-3
8.5.6	ATM Traffic Descriptor.....	8-4
8.5.7	Broadband Bearer Capability	8-6
8.5.8	Broadband High-layer Information.....	8-7
8.5.9	Broadband Low-layer Information	8-8
8.5.9.1	B-LLI Transfer.....	8-8
8.5.9.2	B-LLI Selection	8-9
8.5.10	Call State	8-10
8.5.11	Called Party Number.....	8-10
8.5.11.1	Extended E.164 Addressing.....	8-11
8.5.11.2	ATM Endsystem Address	8-11
8.5.12	Called Party Subaddress.....	8-13
8.5.13	Calling Party Number	8-14
8.5.13.1	E.164 ATM Endsystem Address	8-15
8.5.13.2	Additional ATM Endsystem Addresses	8-16
8.5.14	Calling Party Subaddress	8-17

8.5.15	Cause	8-17
8.5.16	Connection Identifier	8-18
8.5.17	End-to-End Transit Delay	8-18
8.5.18	Quality of Service Parameter	8-18
8.5.19	Broadband Repeat Indicator.....	8-20
8.5.20	Restart Indicator	8-20
8.5.21	Broadband Sending Complete.....	8-20
8.5.22	Transit Network Selection.....	8-20
8.5.23	Endpoint Reference	8-21
8.5.24	Endpoint State	8-21
8.6	ATM Forum Specified Information Elements	8-21
8.7	National-Specific Information Elements.....	8-21
8.7.1	Operator System Access	8-21
9.	Alerting Procedures and N-ISDN Interworking	9-1
9.1	General	9-1
9.1.1	Introduction	9-1
9.1.2	Reference Model	9-1
9.2	Procedures	9-2
9.2.1	Alerting Procedures at an ATM UNI	9-2
9.2.1.1	Call/Connection Establishment at the Originating Interface: Point-to-point Call Origination	9-2
9.2.1.2	Call/Connection Establishment at the Destination Interface: Point-to-Point Call Offering	9-2
9.2.2	Interworking Function.....	9-3
9.2.2.1	Call Origination Treatment.....	9-3
9.2.2.1.1	Originating Signaling.....	9-3
9.2.2.1.2	Interworking.....	9-6
9.2.2.1.3	Answer Message	9-7
9.2.2.2	Call Termination Treatment.....	9-7
9.2.2.2.1	Normal Procedures	9-7
9.2.2.2.2	Interworking.....	9-8
9.2.2.2.3	Speech/3.1-kHz Bearers.....	9-8
9.2.2.3	Clearing Procedures	9-8
9.2.2.4	Restart Procedures	9-9
9.2.2.5	Handling of Error Conditions	9-9
9.3	Additional Procedures and Parameters	9-9
9.3.1	Parameters	9-9
9.3.1.1	ATM UNI	9-9
9.3.2	Timers - ATM UNI	9-10
9.4	Message Functional Definition and Content.....	9-10
9.4.1	SETUP.....	9-10
9.4.2	ALERTING.....	9-10
9.4.3	Progress	9-11
9.5	General Message Format and Information Element Coding.....	9-11

9.5.1	Message Type.....	9-11
9.5.2	Call State	9-11
9.5.3	Narrowband Bearer Capability	9-11
9.5.4	Narrowband High Layer Compatibility	9-13
9.5.5	Narrowband Low Layer Compatibility	9-14
9.5.6	Progress Indicator.....	9-14
9.6	Supplemental Procedures	9-16
9.6.1	Interworking Diagrams	9-16
9.6.2	Examples	9-17
10.	Negotiation.....	10-1
10.1	General	10-1
10.2	Procedures	10-1
10.2.1	Call/Connection Establishment at the Originating Interface	10-1
10.2.2	Call/Connection Establishment at the Destination Interface Point-to-Point Access Call Offering.....	10-2
10.3	Additional Procedures and Parameters	10-4
10.4	Message Functional Definition and Content	10-4
10.4.1	SETUP Message.....	10-4
10.4.2	CONNECT Message	10-5
10.5	General Message Format and Information Element Coding.....	10-5
10.5.1	Alternative ATM Traffic Descriptor	10-5
10.5.2	Minimum Acceptable Traffic Descriptor.....	10-5
	Appendix A: Differences from ATM Forum UNI Specification	A-1
	Appendix B: PRI-based N-ISDN Interworking.....	B-1
B.1	General	B-1
B.1.1	Introduction	B-1
B.1.2	Reference Model	B-1
B.2	Procedures	B-1
B.2.1	Alerting Procedures at an ATM UNI.....	B-1
B.2.2	Interworking Function.....	B-2
B.2.2.1	Call Origination Treatment.....	B-2
B.2.2.1.1	Originating Signaling	B-2
B.2.2.1.2	Interworking.....	B-2
B.2.2.2	Call Termination Treatment.....	B-3
B.3	Additional Procedures and Parameters	B-4
B.3.1	Parameters	B-4
B.3.1.1	ATM UNI	B-4
B.3.1.2	PRI	B-4
B.3.2	Timers - ATM UNI	B-5
B.3.3	D-channel Switchover	B-5
B.4	Message Functional Definition and Content	B-5
B.5	General Message Format and Information Element Coding.....	B-5

References	References-1
Acronyms.....	Acronyms-1

List of Figures

Figure 1-1.	Reference Configuration for Broadband Access Signaling.....	1-1
Figure 3-1.	Relation of SAAL with ATM Layer and Network SVC	3-3
Figure 6-1.	ICD/DCC AESA Index.....	6-5
Figure 8-1.	E.164 AESA	8-12
Figure 8-2.	DCC and ICD AESAs	8-13
Figure 9-1.	Narrowband Interworking Scenario 1	9-2
Figure B-1.	Narrowband Interworking Scenario 2	B-1

List of Tables

Table 2-1.	Summary of SVC Requirements	2-2
Table 3-1.	Summary of Physical Layer for SVC Services.....	3-1
Table 3-2.	SSCOP Timers and Parameter Values.....	3-4
Table 3-3.	SSCOP Parameter Recommendations for Different Interface Rates.....	3-5
Table 4-1.	Additional Network Action on Unsolicited STATUS Messages	4-4
Table 6-1.	Default SCR Values.....	6-2
Table 6-2.	E.164 Block Assignment	6-4
Table 6-3.	Subscription Parameters Per Interface.....	6-10
Table 6-4.	Parameters for BSS.....	6-10
Table 7-1.	Messages for ATM Point-to-Point Call/Connection Control	7-1
Table 7-2.	Parameter Requests in SETUP for Circuit-switching Applications	7-5
Table 7-3.	Parameter Requests in SETUP for VBR Applications	7-6
Table 7-4.	Parameter Requests in SETUP for Unspecified Bit Rate	7-6
Table 7-5.	Messages for Point-to-Multipoint Call/Connection Control	7-7
Table 8-1.	Summary of B-LLI Selection	8-9
Table 8-2.	Summary of B-LLI Selection at Called User	8-10
Table 8-3.	QoS Class 1 Objectives Across a BSS for ATM SVC	8-19
Table 8-4.	QoS Class 3 Objectives Across a BSS for ATM SVC	8-19
Table 8-5.	QoS Class 4 Objectives Across a BSS for ATM SVC	8-19
Table 8-6.	Operator System Access Information Element.....	8-22
Table 9-1.	Summary of Valid Requests for Voice band Bearers	9-5
Table 9-2.	Summary of Valid Request for Circuit-mode Data Bearers	9-6
Table 9-3.	Narrowband Bearer Capability Contents.....	9-12
Table 9-4.	Progress Indicator Contents	9-14
Table 9-5.	Mapping of setup procedure parameters for interworking call	9-16
Table 9-6.	Mapping of alerting (optional).....	9-16
Table 9-7.	Mapping of alerting, independent of ACM	9-17
Table 9-8.	Mapping of answer indication, non-automatic answering terminal	9-17
Table 9-9.	Mapping of release procedures	9-17
Table 9-10.	Mapping of release complete.....	9-17
Table 9-11.	Example SETUP Message to the BSS.....	9-18
Table 10-1.	SETUP Additional Message Contents.....	10-4
Table 10-2.	CONNECT Additional Message Contents	10-5
Table 10-3.	Minimum Acceptable Traffic Descriptor	10-6
Table 10-4.	Allowed Combinations of Traffic Parameters	10-7
Table A-1.	Differences from ATM Forum UNI Specification	A-2