

## Contents

## Telcordia SR-NWT-002723-Documentation Information

1. Intent of Document . . . . .	1-1
2. Scope . . . . .	2-1
3. TL1 Messages . . . . .	3-1
3.1 Operations Areas for TL1 Messages . . . . .	3-1
3.2 Functional Overlaps in Operations Areas . . . . .	3-1
4. Mapping SONET Requirements to TL1 Messages . . . . .	4-1
4.1 Security . . . . .	4-1
4.1.1 User-initiated Security Messages . . . . .	4-1
4.1.2 Security Administrator Initiated Messages . . . . .	4-2
4.1.3 NE Initiated Messages . . . . .	4-3
4.2 Memory Administration . . . . .	4-3
4.2.1 Provisionable Data In SONET NEs . . . . .	4-4
4.2.2 SONET termination points . . . . .	4-5
4.2.3 Linear Automatic Protection Switching (APS) . . . . .	4-5
4.2.4 Payload Mappings and Cross-Connections . . . . .	4-5
4.2.5 Provisioning the Section DCC . . . . .	4-6
4.2.6 Identifying Synchronization Sources and Characteristics . . . . .	4-7
4.2.7 Provisioning Surveillance-Related Data via Memory Administration . . . . .	4-8
4.2.8 System Backup . . . . .	4-8
4.3 Network Maintenance . . . . .	4-8
4.3.1 Alarm Surveillance Functions . . . . .	4-9
4.3.2 Performance Monitoring Functions . . . . .	4-10
4.3.3 Testing Process . . . . .	4-11
4.3.4 Protection Switching . . . . .	4-12
4.3.5 Maintenance Associated with Synchronization . . . . .	4-13
5. Special Architectures . . . . .	5-1
5.1 Unidirectional Path Switched Rings . . . . .	5-1
5.1.1 Memory Administration . . . . .	5-1
5.1.2 Network Maintenance . . . . .	5-2
5.2 Bidirectional Line Switched rings . . . . .	5-2
5.2.1 Memory Administration . . . . .	5-2
5.2.2 Network Maintenance . . . . .	5-3
5.3 IDLC and FITL Systems . . . . .	5-3
Appendix A: Mapping SONET Generic Criteria to TL1 Messages . . . . .	A-1
Appendix B: TL1 Messages for SONET NEs . . . . .	B-1
B.1 OS to SONET NE TL1 Messages . . . . .	B-1
B.2 SONET NE to OS Automatic TL1 Messages . . . . .	B-11
B.3 Condition Types Applicable to SONET NEs . . . . .	B-12

Appendix C: TL1 Messages for FITL Systems . . . . . C-1  
    C.1 OS to FITL System TL1 Messages . . . . . C-1  
    C.2 FITL System to OS Automatic TL1 Messages . . . . . C-5  
    C.3 Condition Types Unique to FITL Systems . . . . . C-6  
Appendix D: TL1 Messages and IDLC Systems . . . . . D-1  
    D.1 Applicable TL1 Commands . . . . . D-1  
    D.2 TL1 Messages . . . . . D-8  
Appendix E: References . . . . . E-1

## List of Tables

Table A-1	Mapping SONET Generic Criteria to TL1 Messages . . . . .	A-2
Table A-1	Mapping SONET Generic Criteria to TL1 Messages, Continued . .	A-3
Table A-1	Mapping SONET Generic Criteria to TL1 Messages, Continued . .	A-4
Table A-1	Mapping SONET Generic Criteria to TL1 Messages, Continued . .	A-5
Table A-1	Mapping SONET Generic Criteria to TL1 Messages, Continued . .	A-6
Table A-1	Mapping SONET Generic Criteria to TL1 Messages . . . . .	A-7
Table B-1	OS to SONET NE TL1 Messages . . . . .	B-2
Table B-1	OS to SONET NE TL1 Messages, Continued . . . . .	B-3
Table B-1	OS to SONET NE TL1 Messages, Continued . . . . .	B-4
Table B-1	OS to SONET NE TL1 Messages, Continued . . . . .	B-5
Table B-1	OS to SONET NE TL1 Messages, Continued . . . . .	B-6
Table B-1	OS to SONET NE TL1 Messages, Continued . . . . .	B-7
Table B-1	OS to SONET NE TL1 Messages, Continued . . . . .	B-8
Table B-1	OS to SONET NE TL1 Messages, Continued . . . . .	B-9
Table B-1	OS to SONET NE TL1 Messages, Continued . . . . .	B-10
Table B-1	OS to SONET NE TL1 Messages, Continued . . . . .	B-11
Table B-2	SONET NE to OS Automatic TL1 Messages . . . . .	B-12
Table B-2	SONET NE to OS Automatic TL1 Messages . . . . .	B-12
Table C-1	OS to FITL System TL1 Messages . . . . .	C-1
Table C-1	OS to FITL System TL1 Messages, Continued . . . . .	C-2
Table C-1	OS to FITL System TL1 Messages, Continued . . . . .	C-3
Table C-1	OS to FITL System TL1 Messages, Continued . . . . .	C-4
Table C-1	OS to FITL System TL1 Messages, Continued . . . . .	C-5
Table C-2	FITL System to OS Messages . . . . .	C-6
Table D-1	OS-initiated TL1 Messages for IDLC System . . . . .	D-2
Table D-1	OS-initiated TL1 Messages for IDLC System, Continued . . . . .	D-3
Table D-1	OS-initiated TL1 Messages for IDLC System, Continued . . . . .	D-4
Table D-1	OS-initiated TL1 Messages for IDLC System, Continued . . . . .	D-5
Table D-1	OS-initiated TL1 Messages for IDLC System, Continued . . . . .	D-6
Table D-1	OS-initiated TL1 Messages for IDLC System, Continued . . . . .	D-7
Table D-1	OS-initiated TL1 Messages for IDLC System, Continued . . . . .	D-7
Table D-2	OS-destined TL1 Messages about IDLC System . . . . .	D-8