

Table of Contents

- Preface** xi
- 1 Introduction**
 - 1.1 Scope of This Document 1-1
 - 1.2 Organization 1-1
 - 1.3 Requirement Statement for GR-833-CORE 1-2
 - 1.4 Reasons for Reissue 1-3
 - 1.4.1 Changes from Issue 6 to Issue 7 1-3
 - 1.5 Requirements Terminology 1-3
 - 1.6 Requirement Labeling Conventions 1-4
 - 1.6.1 Numbering of Requirement and Related Objects 1-4
 - 1.6.2 Requirement, Conditional Requirement, and Objective Identification . . . 1-5
- 2 Types of NEs and Addressing Rules**
 - 2.1 NE Types 2-1
 - 2.2 Addressing Rules 2-2
 - 2.2.1 Access Parameters 2-2
 - 2.2.1.1 Equipment AID 2-3
 - 2.2.1.2 Facility AID 2-3
 - 2.2.1.3 ISDN AIDs 2-5
 - 2.2.1.4 Subscriber Line AIDs 2-6
 - 2.2.1.5 Link AIDs 2-7
 - 2.2.1.6 Packet Link AIDs 2-7
 - 2.2.1.7 Signaling Link AIDs 2-7
 - 2.2.1.8 Trunk AIDs 2-8
 - 2.2.1.9 Test Access AIDs 2-8
 - 2.2.1.10 Other AIDs 2-9
 - 2.2.2 Routing Parameter (TID) 2-9
 - 2.2.2.1 Direct Routing 2-9
 - 2.2.2.2 Indirect Routing 2-9
- 3 Maintenance and Surveillance Categories**
 - 3.1 Maintenance and Surveillance Functional Descriptions 3-1
 - 3.1.1 Alarm Surveillance Functions 3-1
 - 3.1.1.1 Trouble Reporting 3-1
 - 3.1.1.2 Trouble Reporting Controls 3-2
 - 3.1.1.3 Alarm Controls 3-2
 - 3.1.1.4 Status Retrieval 3-2
 - 3.1.2 Performance Monitoring (PM) 3-2
 - 3.1.2.1 Threshold Control 3-2
 - 3.1.3 Failure Identification Functions 3-3
 - 3.1.3.1 Exercises 3-3
 - 3.1.3.2 Diagnostics 3-3
 - 3.1.3.3 Audits 3-3
 - 3.1.3.4 Line Insulation Tests 3-3
 - 3.1.3.5 Automatic Trunk Tests 3-3

- 3.1.3.6 Failure Identification Inhibits 3-4
- 3.1.4 Recovery and Control Functions 3-4
 - 3.1.4.1 Maintenance State Control 3-4
 - 3.1.4.2 Loopbacks 3-4
 - 3.1.4.3 External Device Control 3-4
 - 3.1.4.4 Initialization 3-4
 - 3.1.4.5 Process Inhibit and Termination 3-5
 - 3.1.4.6 Switching 3-5
- 3.1.5 Maintenance Measurement (MM) Functions 3-5
- 3.1.6 Memory Backup (MB) Functions 3-5

4 Input Commands and Responses

- 4.1 Conventions and Notations 4-1
 - 4.1.1 Optional Parameters 4-2
 - 4.1.2 Case Sensitivity 4-3
- 4.2 Specification Format 4-3
- 4.3 Format Explanation 4-6
 - 4.3.1 Command Verb 4-6
 - 4.3.2 Access Identifier (<aid>) 4-6
 - 4.3.3 Correlation Tag (<ctag>) 4-6
 - 4.3.4 Parameter Blocks 4-7
 - 4.3.4.1 Grouping of Parameter Arguments 4-8
 - 4.3.5 General Block 4-8
 - 4.3.6 Acknowledgment 4-9
 - 4.3.7 Response Header 4-10
 - 4.3.8 Completion Code 4-10
 - 4.3.8.1 Completion Code Semantics 4-10
 - 4.3.8.2 Completion Code Usage 4-11
 - 4.3.8.3 Timing of Responses 4-11
 - 4.3.8.4 Null Actions 4-12
- 4.4 Input Command and Response Message Specification 4-13

5 Automatic Messages

- 5.1 Conventions and Notations 5-1
- 5.2 Specification Format 5-1
- 5.3 Format Explanation 5-2
 - 5.3.1 Message Header (<rsphdr>) 5-2
 - 5.3.2 Alarm Code (<almcde>) 5-2
 - 5.3.3 Automatic Tag (<atag>) 5-2
 - 5.3.4 Message Verb 5-3
 - 5.3.5 Access Identifier (<aid>) 5-4
 - 5.3.6 Parameter Blocks 5-4
- 5.4 Automatic Message Specification 5-4

Appendix A: Circuit/Facility/Payload Level Code

Appendix B: Error Codes

Appendix C: Condition Types

C.1 Condtype Structure	C-1
C.2 Use of AIDs and Condtypes	C-2

Appendix D: Maintenance State Types

Appendix E: Monitored Parameter Types and Values

E.1 Montype Structure	E-1
E.2 Construction and Examples of Montypes	E-2

Appendix F: Environmental Alarm Types

Appendix G: External Control Types

Appendix H: Transmission Format and Data Rate Setting

Appendix I: Line Insulation Test Resistance Ranges

Appendix J: Maintenance Measurements Reports

Appendix K: Supplemental Information

Appendix L: Parameter Definitions and Rules

Appendix M: Recommendations for Processing Multiple AIDs

Appendix N: Setting PM Thresholding Parameters Using a GOS Concept

Appendix O: References

O.1 Telcordia Documents	O-1
O.2 External Documents	O-3
O.3 Telcordia Reference Notes	O-4

Appendix P: Acronyms

Requirement-Object Index

List of Figures

Figure K-1 Local Access: DSL K-1

List of Tables

Table 4-1	Acknowledgment Responses	4-9
Table A-1	Plesiochronous Digital Hierarchy (PDH) Values for the Command Code Modifier rr, and Designators	A-1
Table A-2	SONET Values for the Command Code Modifier rr, and Designators	A-2
Table A-3	Ethernet Values for the Command Code Modifier rr, and Designators	A-3
Table A-4	WDM Values for the Command Code Modifier rr, and Designators	A-3
Table A-5	OTN Values for the Command Code Modifier rr, and Designators	A-4
Table A-6	PON Values for the Command Code Modifier rr, and Designators	A-4
Table B-1	Valid Values for Error Codes	B-1
Table C-1	Trouble Conditions	C-2
Table C-2	Irregularities and Error Conditions	C-9
Table C-3	Off-Normal Conditions	C-13
Table C-4	Miscellaneous Conditions	C-16
Table C-5	Alphabetical Listing of Conditions Along With Their Condition Categories	C-17
Table C-6	Transmission Level Values	C-29
Table E-1	Valid Values for the <montype> and <monval> Parameters	E-2
Table E-2	Valid Values for the <montype> and <monval> Parameters	E-7
Table F-1	Valid Values for the <almttype> Parameter	F-1
Table G-1	Valid Values for the <conttype> Parameter	G-1
Table H-1	Valid Values for the <optnm> and <optstg> Parameters	H-1
Table I-1	Valid Values for the <rescde> and <strplev> Parameters	I-1
Table J-1	Valid Values for the <mmrept> Parameter	J-1

