

Table of Contents

1 Introduction

1.1 General	1-1
1.2 Disclaimer	1-1
1.3 Reasons for Reissue	1-1
1.4 Related Documents	1-2
1.4.1 TL1 Interface Documents	1-2

2 Overview of the Transport Element Activation Manager Interface

2.1 NE Types Supported By Transport	2-2
2.2 Information Transferred Over the Transport System to Generic NE Interface	2-2
2.3 Basic Transport Functionality	2-2
2.4 Enhanced Transport Features	2-4
2.4.1 Network Element Memory Backup and Restore	2-4
2.4.2 Software Download	2-4
2.4.3 Virtual Concatenation (VCAT) and Link Capacity Activation Service (LCAS)	2-4
2.4.4 Data Synchronization	2-5
2.5 NE Provider Responsibility	2-5

3 Protocol and Language

3.1 TL1 Interface Support	3-1
3.1.1 Syntax and Message Character Set	3-1
3.1.2 Command Structure	3-1
3.1.3 Target Identifier (TID)	3-2
3.1.4 Access Identifier (AID)	3-3
3.1.5 Correlation Tag (CTAG)	3-4
3.1.6 General Block	3-5
3.1.7 Data Blocks	3-5
3.1.8 Acknowledgements	3-5
3.1.9 Normal Response	3-6
3.1.10 Error Responses	3-6
3.1.11 Autonomous Messages (REPT^DBCHG)	3-6
3.2 SNMP Interface Support	3-7
3.3 CMIP Interface Support	3-8

4 Equipment Provisioning and Utilities

4.1 TL1 Commands	4-1
4.2 Implementation Considerations for Equipment Provisioning	4-2
4.2.1 Equipment Auto Provisioning and Pre-Provisioning	4-2
4.2.2 Equipment Order Pre-Validation	4-3
4.2.3 Facility Protection	4-4
4.2.4 Equipment Hierarchy and the Decoupling Feature	4-4
4.2.5 BLSR Ring Map	4-5
4.2.6 Data Base Conversion	4-5
4.3 Equipment Utilities	4-5

5 Cross Connect Provisioning and Utilities

5.1 Transport Cross Connect Provisioning	5-1
5.2 Transport 'Generic' Cross Connect Types	5-1
5.2.1 2WAY Cross Connect	5-2
5.2.2 2WAYPR Cross Connect	5-3
5.2.3 2WAYBR Cross Connect	5-4
5.2.4 2WAYBB Cross Connect	5-5
5.2.5 INTRUU Cross Connect	5-6
5.2.6 INTRBR	5-7
5.3 INTRBB	5-8
5.4 INTRUB	5-9
5.5 TL1 Cross Connect Messages	5-9
5.6 Two-Way, Two-Point Cross Connect Patching	5-10
5.7 Conference Circuits	5-10
5.7.1 DS3/DS1 Broadcast Conferences	5-10
5.7.2 DS0 Conference Circuits	5-11
5.7.3 Subrate Circuits	5-14
5.8 Cross Connect Pre-Validation	5-14
5.9 Cross Connect Considerations	5-15

Appendix A: References



List of Figures

Figure 5-1	Transport 2WAY Cross Connect	5-2
Figure 5-2	Transport 2WAYPR Cross Connect	5-3
Figure 5-3	Transport 2WAYBR Cross Connect	5-4
Figure 5-4	Transport 2WAYBB Cross Connect	5-5
Figure 5-5	INTRUU Cross Connect	5-6
Figure 5-6	Transport INTRBR Cross Connect	5-7
Figure 5-7	Transport INTRBB Cross Connect	5-8
Figure 5-8	Transport INTRUB Cross Connect	5-9

List of Tables

Table 4-1	TL1 Equipment Provisioning Commands Supported	4-1
Table 5-1	TL1 Cross Connect Provisioning Commands Supported	5-1
Table 5-2	Cross Connect Provisioning	5-9
Table 5-3	Broadcast Conference - Tx Provisioning (x=1 or 3)	5-10
Table 5-4	Broadcast Conference - T0 Provisioning, Case 1	5-11
Table 5-5	Broadcast Conference - T0 Provisioning, Case 2	5-12
Table 5-6	DMB Conference - T0 Provisioning, Case 1	5-13
Table 5-7	DMB Conference - T0 Provisioning, Case 2	5-13
Table 5-8	Subrate Cross Connect Provisioning	5-14