

## Contents

Preface . . . . .	Preface-1
1. Introduction . . . . .	1-1
1.1 Purpose and Scope . . . . .	1-1
1.2 Target Audience . . . . .	1-2
1.3 Structure of This Document . . . . .	1-2
1.4 Requirements Terminology . . . . .	1-2
1.5 Requirement Labeling Conventions . . . . .	1-3
1.5.1 Numbering of Requirement and Related Objects . . . . .	1-3
1.5.2 Requirement, Conditional Requirement, and Objective Object Identification . . . . .	1-4
2. WDM Technology and Network Architectures . . . . .	2-1
2.1 Overview of WDM Technology . . . . .	2-1
2.1.1 Functional Definitions of ONEs . . . . .	2-2
2.2 Network Architectures . . . . .	2-6
2.2.1 Point-to-Point . . . . .	2-6
2.2.2 Linear Chain . . . . .	2-8
2.2.3 Optical Channel Dedicated Protection Ring (OChDPRING) . . . . .	2-9
3. Management Architectures . . . . .	3-1
3.1 TMN Logical Architecture . . . . .	3-1
3.1.1 Management Functional Areas of an Optical Transport Network . . . . .	3-1
3.1.2 Logical Layers . . . . .	3-2
3.2 Benefits of Implementing a TMN . . . . .	3-5
3.3 NMS Architecture . . . . .	3-6
3.4 EMS Architecture . . . . .	3-7
4. Operations Functional Requirements . . . . .	4-1
4.1 Configuration Management . . . . .	4-1
4.1.1 Overview of Subnetwork/Topology Management . . . . .	4-1
4.1.2 Installation Support . . . . .	4-3
4.1.2.1 EMS Installation Support . . . . .	4-3
4.1.2.2 ONE Installation Support . . . . .	4-3
4.1.2.2.1 Installation of ONE Software . . . . .	4-3
4.1.2.2.2 Activation of ONE Software . . . . .	4-4
4.1.2.2.3 Scheduling of Installation/Activation . . . . .	4-4
4.1.2.2.4 Hardware Installation Completion Report . . . . .	4-4
4.1.3 Inventory Management . . . . .	4-4
4.1.3.1 Inventory Retrieval . . . . .	4-5
4.1.3.1.1 EMS and ONE Identification . . . . .	4-5
4.1.3.1.2 Physical Termination Points . . . . .	4-5
4.1.3.1.3 Edge Termination Points . . . . .	4-5
4.1.3.1.4 Subnetwork Names . . . . .	4-5

4.1.3.1.5	Topological Links . . . . .	4-6
4.1.3.1.6	Subnetwork Connections . . . . .	4-6
4.1.3.1.7	Protection Switching . . . . .	4-9
4.1.3.1.8	Circuit Inventory Retrieval . . . . .	4-9
4.1.3.1.9	Equipment Inventory Retrieval . . . . .	4-12
4.1.3.2	Inventory Notification . . . . .	4-12
4.1.3.2.1	EMS and ONE Installation . . . . .	4-12
4.1.3.2.2	Subnetwork Connections . . . . .	4-13
4.1.3.2.3	Protection Switching . . . . .	4-14
4.1.3.2.4	Circuit Inventory Notification . . . . .	4-15
4.1.3.2.5	Equipment Inventory Notification . . . . .	4-15
4.1.4	Provisioning . . . . .	4-15
4.1.4.1	ONE Configuration . . . . .	4-15
4.1.4.1.1	Success/Failure Response to Configuration Requests . . . . .	4-16
4.1.4.2	Subnetwork Configuration . . . . .	4-17
4.1.4.2.1	Resource Selection and Assignment in EMS . . . . .	4-17
4.1.4.2.2	Resource Activation in ONE . . . . .	4-17
4.1.4.3	Ring Interconnection . . . . .	4-18
4.1.4.4	Topology Management . . . . .	4-18
4.2	Protection Management . . . . .	4-20
4.2.1	Protection Switching . . . . .	4-21
4.2.2	OChDPRING . . . . .	4-21
4.2.3	Interconnection . . . . .	4-23
4.3	Connection Management . . . . .	4-23
4.3.1	Subnetwork Connection Management . . . . .	4-23
4.4	Fault Management . . . . .	4-26
4.4.1	Alarm Surveillance . . . . .	4-27
4.4.1.1	Alarm Reporting . . . . .	4-27
4.4.1.2	Alarm Summary Control . . . . .	4-27
4.4.1.3	Alarm Log Control . . . . .	4-28
4.4.1.4	Alarm Correlation and Filtering . . . . .	4-28
4.4.2	Fault Localization . . . . .	4-31
4.4.3	Fault Correction . . . . .	4-32
4.4.3.1	ONE Fault Correction . . . . .	4-32
4.4.4	Testing . . . . .	4-32
4.4.5	NMS-EMS Communication Status Monitoring . . . . .	4-32
4.5	Performance Management . . . . .	4-33
4.5.1	Performance Monitoring . . . . .	4-33
4.5.1.1	Performance Data Accumulation . . . . .	4-34
4.5.1.2	Performance Data Reporting . . . . .	4-37
4.5.1.3	Data Aggregation and Trending . . . . .	4-38
4.5.2	Performance Management Control . . . . .	4-39
4.5.2.1	Control of Periodic PM Data Collection . . . . .	4-39
4.6	Security Management . . . . .	4-42

5. Management Paradigms for the NMS-EMS Interface . . . . .	5-1
5.1 Defining an Information Model . . . . .	5-1
5.2 Defining a Computational Model . . . . .	5-2
References . . . . .	References-1
Acronyms . . . . .	Acronyms-1
Requirement-Object Index . . . . .	ROI-1



## List of Figures

Figure 2-1.	Two-Channel, Unidirectional, Point-to-Point WDM System . . .	2-1
Figure 2-2.	Two-Channel, Bidirectional, Point-to-Point WDM System . . .	2-2
Figure 2-3.	Wavelength-Path and Light-Path Optical Connections . . . . .	2-4
Figure 2-4.	Full and Limited Wavelength Interchange in an n-wavelength System. . . . .	2-5
Figure 2-5.	Point-to-Point Configuration . . . . .	2-6
Figure 2-6.	Point-to-Point WDM Systems . . . . .	2-7
Figure 2-7.	Point-to-Point WDM Systems with Wavelength Pass-Through .	2-8
Figure 2-8.	Linear Chain with OTMs and OADM . . . . .	2-8
Figure 2-9.	Optical Channel Dedicated Protection Ring (OChDPRING) . .	2-9
Figure 3-1.	TMN Functional Structure . . . . .	3-4
Figure 3-2.	Examples of System Implementation of TMN Logical Layer Functions . . . . .	3-5
Figure 3-3.	Architecture Example . . . . .	3-7
Figure 4-1.	Subnetwork View . . . . .	4-1



## List of Tables

Table 4-1.	Use Case: NMS Requests EMS Inventory Data . . . . .	4-9
Table 4-2.	Use Case: NMS Resynchronizes NMS Data with EMS Data . . .	4-19
Table 4-3.	Use Case: The NMS Activates a Subnetwork Connection . . . .	4-25
Table 4-4.	Use Case: The NMS Changes Filters for All Notifications . . . .	4-29
Table 4-5.	Use Case: The NMS Requests All Active Alarms . . . . .	4-31
Table 4-6.	Use Case: NMS Detects EMS is Unavailable . . . . .	4-33
Table 4-7.	Use Case: Retrieval of Current Performance Monitoring (PM) Data for a Set of TPs . . . . .	4-34
Table 4-8.	Use Case: NMS Sets Threshold on a Termination Point . . . . .	4-36
Table 4-9.	Use Case: NMS Retrieves TCA Parameters on a Termination Point (PTP or CTP) . . . . .	4-37
Table 4-10.	Use Case: NMS Requests Activation of Collection of Performance Monitoring Data by the EMS for a TP . . . . .	4-40
Table 4-11.	Use Case: NMS Requests Deactivation of Collection of Performance Monitoring Data by the EMS for a TP . . . . .	4-41