

Contents

Generic Requirements Notice Of Disclaimer	iii
List of Tables	viii
Preface	ix
Telcordia Interactive GR Process	ix
FA-TA-TR to GR	ix
Transition Phase	ix
Comments and Issues List Report Mechanism	x
GR-2815-CORE Current Maturity Level, Status, and Plans	x
Formatting Comments	xi
Where and When to Submit Comments	xi
1 Introduction	
1.1 Definition	1-1
1.2 Background	1-2
1.2.1 Terminology Definitions	1-2
1.2.2 Terminal Assumptions	1-3
1.3 Requirements Terminology	1-3
1.4 Requirement Labeling Conventions	1-4
1.4.1 Numbering of Requirement and Related Objects	1-4
1.4.2 Requirement, Conditional Requirement, and Objective Identification	1-4
2 The Need for Default Service	
3 Background and Overview	
3.1 NI-1 and NI-2 Terminal Initialization	3-1
3.2 NI-3 Terminal Initialization	3-1
4 Examples of Default Service on Access Lines	
4.1 New Line, No Other Services	4-1
4.2 Existing Non-EKTS Line with No VI capabilities	4-1
4.3 EKTS Line (All DNs are Shared EKTS)	4-1
5 Layer 2 Initialization	
6 Layer 3 Initialization	
6.1 Switch Parameters Needed to Support a NIT	6-1
6.1.1 The Default Service Dummy DN and 911 Service	6-3
6.2 OE [Interface] View Parameters Needed to Support Default Service	6-3
6.3 DNCT View for Default Service	6-4
6.4 OEDN View for Default Service	6-5

6.5 Terminal Service Profile (TSP) View 6-6

Appendix A: References

Note A-2
 To Contact Telcordia Customer Service or to Order Documents A-2
 To Order Documents From Within Telcordia (Employees Only) A-2

Appendix B: Acronyms

Requirement-Object Index

List of Tables

Table 6-1	OE [Interface] View Parameters Needed for Default Service	6-3
Table 6-2	DNCT View Parameters Needed for Default Service	6-4
Table 6-3	OEDN View Parameters Needed for Default Service	6-5