

Contents

[Telcordia SR-OPT-001578-Documentation Information](#)

Special Report Notice of Disclaimer	iii
1 Introduction	
1.1 Disclaimer	1-1
1.2 Reason for Reissue	1-1
1.3 Related Documents	1-1
2 Protocol and Communication	
3 TL1 Language	
3.1 TL1 Command Structure	3-1
3.2 TL1 Capabilities	3-1
3.3 Syntax and Semantics	3-2
4 Implementation of TR-NWT-000199	
4.1 Memory Administration Commands	4-1
4.1.1 Memory Administration Command Parameter Blocks	4-2
4.1.2 Memory Administration Data Parameters	4-3
4.1.3 Memory Administration Command Responses	4-3
4.2 Functional Area Provisioning	4-4
4.2.1 Location Reference Provisioning	4-4
4.2.2 Equipment Provisioning	4-4
4.2.3 SONET Termination Provisioning	4-5
4.2.4 Ty Provisioning	4-6
4.2.5 Two-Point Cross-Connect Provisioning	4-7
4.2.5.1 SONET OCn and ECm Cross-connection	4-7
4.2.5.2 SONET STSp and VTx Cross-connection	4-8
4.2.5.3 DS3 Cross-connection	4-8
4.2.5.4 DS1 Cross-connection	4-9
4.2.5.5 DS0 Cross-connection	4-9
4.2.5.6 One-way Two-point Cross-connections	4-9
4.2.5.7 Two-way, Two-point Cross-connect Patching	4-10
4.2.6 Conference Circuits	4-10
4.2.6.1 DS3/DS1 Broadcast Conferences	4-10
4.2.6.2 DS0 Conference Circuits	4-11
4.2.7 Subrate Circuits	4-14
4.2.8 Administrative and Utility Support	4-14
4.2.8.1 Equipment, Ty, and SONET Level Entities	4-15
4.2.8.2 Cross-Connections	4-16
4.2.8.3 Retrieve Autonomous Output	4-16
4.2.8.4 Autonomous Messages	4-16
4.2.8.5 Security Message Support	4-17

5 Flow-through Support

6 Additional Functions

Appendix A: OPS/INE Memory Administration Data Dictionary

Appendix B: References

Note	B-2
To Contact Telcordia Customer Service or to Order Documents	B-2
To Order Documents From Within Telcordia (Employees Only)	B-2

Appendix C: Acronyms